

Descaling powder RM 511



Effectively descales steam cleaners and other hot-water devices, such as kettles and coffee machines – for long lifetimes and low energy use.



Application areas

- Descaler for Kärcher steam cleaners
- Descaler for coffee machines, kettles etc.

Container sizes	VE*	Part number
3 x 17 g		6.295-982.0
6 x 17 g	15	6.295-987.0
6 x 17 g	15	6.296-193.0

*VE: packaging unit

Application:

Steam cleaners and other household devices

- One packet of powder is added to a container (e.g. a measuring cup) and stirred into 0.5 litres of cold water until it dissolves.
- Pour the descaler into the device (e.g. steam cleaner, kettle).
- Rinse the device at least twice after the descaling process.
- After this, you can use the device as normal.

Warnings and safety recommendations according to EC Directives:

- Warning
- H319 Causes serious eye irritation
- H335 May cause respiratory irritation
- P101 If medical advice is needed, have product container or label at hand.
- P102 Keep out of reach of children.
- P261 Avoid breathing dust/fume/gas/mist/vapours/spray.
- P280i Wear eye/face protection.
- P304 + P340 IF INHALED: Remove person to fresh air and keep comfortable for breathing.
- P305 + P351 + P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- P405 Store locked up.
- P501a Dispose of contents/container in accordance with local/regional/national/international regulations.

Please contact us for more information:

Alfred Kärcher SE & Co. KG

Alfred-Kärcher Straße 28-40
71364 Winnenden

Phone +49(0)7195-14-0
Fax +49(0)7195-14-2212

www.kaercher.com